

# Roland® MV-8800

## System Update Procedure

### Updating Via USB

#### What Do I Need?

- The Update File "MV8800.PRG" included with this download
- PC or Mac that fulfills the MV-8800's operating requirements
- USB cable

#### How Do I Update?

1. **Connect the MV-8800 to your computer via a USB cable.**
2. **Press [DISK/USB].**
3. **Press [F3 (USB)].**
4. **Press [F5 (Connect)].**

The message "Save Project?" appears.

5. **Press [F1 (No)].**

On a Mac, the MV-8800's hard drive appears on the desktop. On a PC, the MV-8800's hard drive appears inside "My Computer".

6. **Drag the file "MV8800.PRG" to the MV-8800's hard disk. Do not place it inside any other folder.**
7. **Once the file has been transferred, eject the MV-8800's drive from your computer.**

On a Mac, drag the MV-8800 hard drive to the trash. On a PC, right-click on the MV-8800 hard drive and select "Eject".

8. **Shut down the MV-8800.**
9. **While holding [SONG] and [DISK/USB], turn the MV-8800 back on. Hold the buttons until the following screen appears:**

```
Roland MV-8800 PRODUCTION STUDIO
** HD Update Mode **
```



**IMPORTANT:** Never shut down the MV-8800 while the update is in process.

When the update has been completed, the version number will be displayed and all LEDs will flash.

10. **Restart the MV-8800.**

### Updating Via CD-ROM

#### What Do I Need?

- The Update File "MV8800.PRG" included with this download
- A blank CD-R
- PC or Mac with CD burner
- Some sort of CD burning software that can burn ISO 9660 format CD-ROMs (such as Nero, EZ CD Creator, or Toast)

#### How Do I Update?

1. **Burn *only* the "MV8800.PRG" file to an ISO 9660-format CD-ROM.**



**NOTE:** Burning a Windows or Mac-format CD-ROM will not work.

2. **Insert the ISO 9660 format CD-ROM into the MV-8800's CD drive.**
3. **Shut down the MV-8800.**
4. **While holding [INSTRUMENT] and [DISK/USB], turn the MV-8800 back on. Hold the buttons until the following screen appears:**

```
Roland MV-8800 PRODUCTION STUDIO
** CD-ROM Update Mode **
```



**IMPORTANT:** Never shut down the MV-8800 while the update is in process.

When the update has been completed, the version number will be displayed and all LEDs will flash.

5. **Restart the MV-8800.**